


NAMES AND FUNCTION OF PARTS



Thank you for purchasing this Wine Bottle Cooler/ Warmer, Before use, please read the safety information and precautions contained in the following sections to ensure safe use of this product.

I. FEATURES

Wine Bottle Cooler/ Warmer, using Peltier and CPU technology to control 10 temperature settings (min, 37, 43,48, 54, 59, 64, 70, 75, 122°F) designed for cooling, warming and keeping constant temperature for various kind of wines (such as white wines, red wines, Japanese Sake...etc). Very easy to control the wine at optimum temperature.

- (1) Blue "Cooling" LED light
- (2) Red "Warming" LED light
- (3) 10 green LED lights to indicate temperatures at (min, 37, 43, 48, 54, 59, 64, 70, 75 and 122°F)
- (4) "Down" button to move temperature setting downward.
- (5) "Up' button to move temperature setting upward.
- (6) Aluminium container with 90mm diameter
- (7) DC power inlet socket
- (8) Air inlet for fan
- (9) Removable air filter
- (10) Air outlet
- (11) AC/DC switching mode power supply
- (12) DC jack
- (13) AC plug with power cord
- (14) Insulation sleeve
- * To avoid electric shock. Do not open.
- * Any repair work must be done by qualified technician appointed by our distributors.
- * Specifications are subject to change for improvement without prior notice.

II. SPECIFICATIONS

- Aluminium container: 3.5 inches diameter
- Temperature settings : 10 settings min, 37, 43, 48, 54, 59, 64, 70, 75

and 122°F


- Fan: 3.5 x 3.5 inches Brushless motor
- High temperature protection : 122°F
- Switching mode power supply : 12 V d.c. 5Amp
- Power consumption : 60W
- Dimension: 0.8(H) x 0.6(W) x 0.8(D) inches


III. CONNECTION

- After removing the packaging materials, there should be 3 items:
 - a. Wine Bottle Cooler/ Warmer unit.
 - b. AC/DC switching mode power supply.
 - c. Insulation Sleeve.
- 2. Plug the DC power jack (12) of the switching mode power supply to the DC socket (7) of the unit, then connect the AC plug (13) of the switching mode power supply to the appropriate mains socket. The default temperature is set at minimum ("min") and the blue "LED" (1) on the control panel that indicates "cooling" will be ON after 5seconds.

IV. OPERATION


You may press the front "Up" Button (5) [as Fig.1] or "Down" Button (4) [as Fig.2] to select your required temperature and the 10 green LED indicators (3) will show your temperature selection. The sensors inside the unit detects the temperature of the aluminium container and the CPU will compare your temperature setting to decide whether it should be "Cooling" or "Warming".






"Cooling" - If the temperature of the aluminium container is higher than the temperature set, the blue "Cooling" LED (1) on the control panel will be on. [as Fig.3]

"Warming" - If the temperature of the aluminium container is lower than the temperature set, the red "Warming" LED (2) on the control panel will be on. [as Fig.4]





When the temperature of the aluminium container has reached the temperature programmed, the blue & red LED on the control panel will both be off, leaving only the green LED that indicates the set temperature on.

It takes the sensor 5seconds to switch from warming to cooling and vice versa.

The main function of this unit is not to only "cool" or "warm" the wine bottle but also in maintaining the temperature. please note that white wine pre-cooled in a refrigerator before putting it in the Wine Bottle Cooler will shorten the time. Otherwise it will take one hour to cool.


For faster cooling or warming effect, the insulation sleeve (14) provided may be used to cover the top part of the bottle. [as Fig.5]

For wine bottles which are smaller than 3.5 inches, we recommend the bottle be placed off centre so that the bottle can be in contact with the wall of aluminium container for effective cooling, The shape of the insulation sleeve can be altered.



V. FILTER CLEANING

The user may take the removable air filter (9) from the bottom of the unit for cleaning or washing. [as Fig.6] Before taking out this air filter, make sure to disconnect the AC plug outlet.



VI. CAUTIONS

- Do not put ice or water inside the container (6).
- After having finished using the Wine Bottle Cooler/ Warmer, the user should disconnect the AC plug (13) to.
- Avoid using the AC/DC switching mode power supply in wet or damp areas.
- Avoid putting any paper, plastic bag or cloth to cover the back of Wine Bottle Cooler/ Warmer unit that may block the air vent.
- In case, when there is more than one green
 "temperature" LED (3) lit at the same time, please unplug the DC socket and plug it again.
- If there is no power coming from the switching mode power supply unit, it should be checked by electrical technician to see if the fuse inside the unit is faulty.

VII. TERMS

Vinotemp International ("Seller") and the person or entity that acquires these goods from Seller ("Purchaser") hereby fully agree to the following terms and conditions of the sale: Shipping fees are the responsibility of the Purchaser whether freight prepaid or freight collect. Seller assumes no responsibility for the goods sold to the Purchaser once the goods have left the Seller's premises, including, but not limited to, late delivery by the moving carrier, or for events caused by any difficulty carrier incurs in attempting to fit the goods into the Purchaser's place of business or residence due to the size of the goods or otherwise. Purchaser assumes all responsibility for delivery, payment of freight, access, measurement, installation, hook-up, wiring, moving and storage of the goods. The transportation of all goods is subject to the terms and conditions which the moving carrier imposes on Purchaser including, but not limited to, additional charges imposed per flight of stairs, and/or additional charges resulting from the carrier's inability to safely and/or adequately use the building elevator to lift the goods to an upper floor. Any claim for damages incurred during shipment by the carrier of the goods are insured and handled directly with the carrier. Any damages due to manufacture defects will be handled directly with Vinotemp International, subject to the limited warranty.

All sales are final, and unless authorized in writing by the Seller, Purchaser may not return the goods, under any circumstance. If Purchaser refuses to accept the goods, under any circumstance, the Purchaser is liable for the return and cost of freight both ways, and if Seller does take back the goods, there will be a restocking charge that is 35% of the purchase price of the goods. Custom Cabinet and Racking are non returnable. Purchaser must notify Seller of non-conforming goods within four days of delivery, after which time all goods are deemed accepted. If an order has been placed and production has started, cancellation of your order will be a 15% charge.

If Purchaser tenders payment with a check that has insufficient funds (NSF), or stops payment on a check or credit card for any reason, Purchaser agrees to pay for all costs associated with the Seller's connection or litigation of such a claim, including without limitation extra damages, court costs and attorneys' fees. Finance charges begin the date of invoice. Collection fees plus NSF fee of 50\$ will be added to your invoice, which you agree to promptly pay. Title to the goods does not pass until payment is received in full by Seller and Seller retains a security interest in the goods until they are paid for in full.

LIMITED WARRANTY: Seller warrants that the goods will be free of defects in materials and workmanship as follows: Furniture style (wood) wine units: all cooling unit parts for a period of 5 (five) years; cabinetry and labor (uninstalled) for a period of 12 (twelve) months from date of sale, removal and re-installation of unit is not included in warranted labor. For the metal cabinet wine units: parts and labor for cooling system and cabinetry for a period of 12 (twelve) months from date of sale, removal and re-installation of unit is not included in warranted labor. For a scratch and dent or refurbished unit, warranty is 3 months from your dated invoice (parts for function only, not cosmetic). Thermoelectric Units: 90 (ninety) days from the date of sale. (This includes Wine Coolers, Beer Dispensers and Refrigerators). Cigar Humidors and Racking Systems are not warranted. Split Systems and installed products are parts only for 1 year, no labor. There is no warranty on parts purchased separately. Purchaser's exclusive remedy is limited, at Seller's option; to repair or replace defective part[s] with either new or factory reconditioned part[s]. Purchaser is responsible for shipping the unit pre-paid to designated facility and Seller will pay return shipping charges in the continental United States for items repaired under warranty within 12 (twelve) months from date of sale. Since the natural variation in texture, density, grain, color, tone and shade of wood is unavoidable; Seller does not guarantee the texture, color, tone or shade of the wood: nor does seller guarantee the colorfastness of wood or against peeling, chipping, cracking or

scratching. Note: Unfinished wood is subject to warping; all wood surfaces must be sealed before placing cellar into service. Improper placement of the unit will void the warranty. This limited warranty does not cover damage due to such things as accident, misuse, abuse, mishandling, neglect, acts of God, fires, earthquakes, floods, high winds, government, war, riot or labor trouble, strikes, lockouts, delay of carrier, unauthorized repair, or any other cause beyond the control of the Seller, whether similar or dissimilar to the foregoing. Seller is not responsible for any damages caused to Seller's property resulting from the good. This limited warranty applies only inside the Continental US. (Alaska, Puerto Rico and Hawaii are not warranted).

With Wine Mate products, if the customer calls and the product is "defective", you must obtain a letter from your qualified refrigeration technician at the customers cost, to verify that the unit was installed properly, with proper ventilation and the unit is truly malfunctioning due to manufacture defect.

Purchaser understands and acknowledges that the goods sold here are wine cellars, cigar humidors, and/or other similar units which house wine or cigars. Purchaser assumes all risk of using these units, including risk of spoilage, humidity variations, temperature variations, leaks, fire, water damage, mold, mildew, dryness and similar and any other perils that might occur.

Seller is not responsible for incidental or consequential damages, and there are no warranties, expressed or implied, which extend beyond the Limited Warranty described above. The implied warranties of merchantability and of fitness for a particular purpose are hereby expressly disclaimed. Some states do not allow the exclusion of incidental or consequential damages, or a waiver of the implied warranties of fitness and/or merchantability, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

In the event of any dispute between Seller and Purchaser arising out of or relating to these terms and conditions or to the goods sold generally, Purchaser must first file a written claim with Seller within ten days of the occurrence giving rise to the claim and wait an additional thirty days for a response before initiating any legal action. The sale and all terms are subject to California law. Any legal proceeding arising out of or relating to these terms and conditions or to the goods sold generally shall be brought solely and exclusively in the County of Los Angeles. In no event may Purchaser initiate any legal proceeding more than six months after the occurrence of the event giving rise to the dispute.

The above terms and conditions are the only ones governing this transaction and Seller makes no oral representations of any kind. These Terms and Conditions can only be modified in writing, signed by both Purchaser and Seller. 04/07

